TOSHIBA

# DVD VIDEO PLAYER
# SD-680KY

## OWNER S'MANUAL

Digital Out




© 2007 Toshiba Corporation

# Introduction

English

## SAFETY PRECAUTIONS


CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
AVIS
RISQUE DE CHOC ELECTRIQUE NE
PAS OUVRIR
WARNING : TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol,within an equilateral triangle,is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product' s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance(servicing) instructions in the literature accompanying the appliance.

The symbol for CLASS II (Double Insulation)

**WARNING:**

**TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE. DANGEROUS HIGH VOLTAGES ARE PRESENT INSIDE THE ENCLOSURE. DO NOT OPEN THE CABINET. REFER SERVICING TO QUALIFIED PERSONNEL ONLY.**

**CAUTION:**

PLEASE READ AND OBSERVE ALL WARNINGS AND INSTRUCTIONS GIVEN IN THIS OWNER' S MANUAL AND THOSE MARKED ON THE UNIT. RETAIN THIS BOOKLET FOR FUTURE REFERENCE.

### IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
10. Only use attachments/accessories specified by the manufacturer.
11. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

12. Unplug this apparatus during lightning storms or when unused for long periods of time.
13. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
14. When you use headphones, keep the volume at a moderate level. If you use the headphones continuously at high volumes, it may cause hearing damage.
15. Do not overload wall outlets; extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
16. Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
17. Keep your fingers well clear of the disc tray as it is closing. Neglecting to do so may cause serious personal injury.
18. Do not place a heavy object on or step on the apparatus. The object may fall, causing serious personal injury and serious damage to the apparatus.
19. Do not use a cracked , deformed, or repaired disc. These discs are easily broken and may cause serious personal injury and apparatus malfunction.
20. If the apparatus should smoke or smell,immediately disconnect the power cord from the wall outlet. Wait until the smoke or smell stops, then ask your dealer for a check and repair. Neglecting to do so may cause fire.
21. While it is thundering, do not touch the connecting cables or the apparatus.
22. The apparatus includes lead, an ingredient of solder used on the PCB, which is a harmful substance to human and the environment.When disposing of this apparatus, follow the rules and regulations in your area.

English

**CAUTION:** This Digital Video Disc Player employs a Laser System.
To ensure proper use of this product, please read this owner's manual carefully and retain for future reference. Should the unit require maintenance, contact an authorized service location.

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

To prevent direct exposure to laser beam, do not try to open the enclosure.
Visible and invisible laser radiation when open and interlocks defeated.
**DO NOT STARE INTO BEAM**.

**CAUTION**: These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.

In the spaces provided below, record the Model and Serial No. located on the rear panel of your DVD video player.
Model No. _____ Serial No. _____
Retain this information for future reference.

**Location of the required label:**



The rating plate and the safety caution are on the rear of the unit.

Be aware that this equipment is still powered when in standby mode. To disconnect this equipment completely from the mains power, pull out the power plug from the wall outlet.

---

This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Use of this copyright protection technology must be authorized by Macrovision, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision. Reverse engineering or disassembly is prohibited.

**Notes on copyright**
The unauthorized recording, use, distribution, or revision of television programs, videotapes, DVDs and other materials, is prohibited under the Copyright laws of the United States and other countries, and may subject you to civil and/or criminal liability.

DivX, DivX Certified, and associated logos are trademarks of DivX, Inc. and are used under license.

" DTS " and " DTS Digital Out " are registered trademarks of DTS, Inc.

Manufactured under license from Dolby Laboratories. " Dolby " and the double-D symbol are trademarks of Dolby Laboratories.

English

## Table of Contents


**Introduction**

| | |
|---|---|
| SAFETY PRECAUTIONS | 1 |
| IMPORTANT SAFETY INSTRUCTIONS | 1 |
| Table of Contents | 3 |
| Region Codes | 4-5 |

**Connections**

| | |
|---|---|
| Connecting to television | 6 |
| Connecting to a stereo system | 7 |
| Connecting to a Digital AV Receiver | 7 |
| Connecting the power cord | 7 |

**Product Overview**

| | |
|---|---|
| Front and Rear panels | 8 |
| Remote Control | 9 |

**Getting Started**

| | |
|---|---|
| Inserting Batteries | 10 |
| Finding your viewing channel | 10 |
| Setting up Progressive Scan feature | 10-11 |
| Setting the language | 11 |

**Playback from Disc**

| | |
|---|---|
| Playable discs | 11-12 |

**Playback Feature**

| | |
|---|---|
| Starting disc playback | 12 |
| Basic playback control | 12 |
| Operations for video playback (DVD/VCD/SVCD) | 13 |
| Selecting various repeat functions | 13-14 |
| Viewing the disc playback information | 14 |
| Special DVD Features | 14 |
| Special VCD and SVCD Features | 14-15 |
| Playing a DivX® Disc | 15 |
| Playing MP3/JPEG/Kodak Picture CD | 15-16 |

**DVD Menu Options**

| | |
|---|---|
| Using the Language setup menu | 16 |
| Using the Video setup menu | 17-18 |
| Using the Audio setup menu | 18 |
| Using the Rating setup menu | 19 |
| Using the Misc (Miscellaneous) setup menu | 19-20 |
| Tray Lock | 20 |

**Others**

| | |
|---|---|
| Specifications | 21 |
| Troubleshooting | 22 |

**DANGER!**
**High voltage! Do not open the device. You run the risk of getting an electric shock.**

**The machine does not contain any user-serviceable parts. Please leave all maintenance work to qualified personnel.**

## Setup

**Finding a suitable location**
-Place the set on a flat, hard and stable surface.
-Do not place the set on a carpet.
-Do not position the set on top of other equipment that might heat it up (e.g., receiver or amplifier).
-Do not put anything under the set (e.g.CDs, magazines).
-Install this unit near the AC outlet and where the AC power plug can be reached easily.

**Space for ventilation**
-Place the apparatus in a location with adequate ventilation to prevent internal heat build up. Allow at least 10 cm (4.0") clearance from the rear and the top of the set and 5 cm (2.0") from the left and right to prevent overheating.




**Avoid high temperatures, moisture, water and dust**
-Apparatus shall not be exposed to dripping or splashing.
-Do not place any sources of danger on the apparatus (e.g., liquid filled objects, lighted candles).

## Cleaning discs

Some problems occur because the disc inside the system is dirty (frozen picture, sound disruptions, picture distortions). To avoid these problems, discs should be cleaned on a regular basis.

To clean a disc, use a micro fibre cleaning cloth and wipe the disc from the center to the edge in a straight line. Do not touch the playback side of the disc.





**CAUTION!**
Do not use solvents such as benzene, thinner, commercially available cleaners, or anti-static sprays intended for analog discs. Since the optical unit (laser) of the DVD system operates at a higher power than regular DVD or CD players, cleaning CDs intended for DVD or CD players may damage the optical unit (laser). Therefore, refrain from using a cleaning CD.

## Moisture Condensation

Moisture condensation damages the DVD video player. Please read the following carefully. Moisture condensation occurs, for example, when you pour a cold drink into a glass on a warm day. Drops of water form on the outside of the glass. In the same way, moisture may condense on the optical pick-up lens inside this unit, one of the most crucial internal parts of the DVD video player.

If you use the DVD video player in such a situation, it may damage discs and internal parts. Remove the disc, connect the power cord of the DVD video player to the wall outlet, turn on the DVD video player, and leave it for two or three hours. After two or three hours, the DVD video player will have warmed up and evaporated any moisture. Keep the DVD video player connected to the wall outlet and moisture condensation will seldom occur.

## Region Codes

This DVD player is designed to support the Region Management System. Check the regional code number on the disc package. If the number does not match the player' s region number (see table on page 5 ), the player may be unable to playback the disc.

*Tips:*
*-It may not be possible to play CD-R/RW , DVD±R/RW or DVD±R DL in all cases due to the type of disc or condition of the recording.*
*-If you are having trouble playing a certain disc, remove the disc and try a different one. Improperly formatted disc will not play on this DVD Player.*

# Introduction (continued)

English

| Region | Discs that can be played |
|---|---|
| U.S.A. and Canada regions |   |
| U.K. , Europe regions and Japan |   |
| Asia Pacific, Taiwan, Korea |   |
| Australia, New Zealand, Latin America |   |
| Russia and India regions |   |
| China, Calcos Islands, Walls and Futuna Islands |   |

***Helpful hint:*** before making or changing any connections, make sure that all the devices are disconnected from the power outlet.

## Connecting to television

**IMPORTANT!**
-**You only need to make one video connection from the following options, depending on the capabilities of your television.**
-**Connect the DVD player directly to the television.**

### Using Composite Video Jack (CVBS)



❶ Use the composite video cable(yellow) to connect the DVD player' s VIDEO OUT (CVBS) jack to the video input jack(or labelled as A / V in , Video In or Composite ) on the TV(cable supplied).
To hear the sound of this DVD Player through your TV, use the audio cables (white/red) to connect AUDIO OUT (L / R) jacks of the DVD player to the corresponding AUDIO IN jacks on the TV ( cable supplied ).

### Using Component Video Jacks(Y PB PR)



**IMPORTANT!**
-**The progressive scan video quality is only possible when using Y PB PR and a progressive scan TV is required.**

❶ Use the component video cables (red/blue/green) to connect the DVD player' s Y PB PR jacks to the Corresponding Component video input jacks (or labelled as Y Pb Pr) on the TV (cable not supplied).
❷ Use the audio cables (white/red) to connect AUDIO OUT (L/R) jacks of the DVD player to the corresponding AUDIO IN jacks on the TV (cable not supplied).
❸ Proceed to page 10 for detailed Progressive Scan set up.

### Using a RF modulator




**IMPORTANT!**
—**If your TV only has a single Antenna In jack (or labelled as 75 ohm or RF In), you will need a RF modulator in order to view the DVD playback on the TV.**

❶ Use the composite video cable (yellow) to connect the DVD player' s VIDEO OUT (CVBS) jack to the video input jack on the RF modulator (cable supplied).
To hear sound of this DVD player through your TV, use the audio cables(white/red) to connect AUDIO OUT (L/R) jacks of the DVD player to the corresponding AUDIO IN jacks on the RF modulator (cable supplied).
❷ Use the RF coaxial cable (not supplied) to connect ANTENNA OUT or TO TV jack on the RF modulator to the ANTENNA IN jack on the television.
❸ Connect the Antenna or Cable TV service signal to the ANTENNA IN or RF IN jack on the RF modulator. (It may have been connected to your TV previously. Disconnect it from the TV.)

***Helpful hint:*** before making or changing any connections, make sure that all the devices are disconnected from the power outlet.

# Connections (continued)

English

## Connecting to a Stereo System




### Stereo System has Dolby Pro Logic or Right/Left Audio In jacks

1. Select one of the video connections (CVBS VIDEO IN or COMPONENT VIDEO IN) depending on the options available on your TV.
2. Use the audio cables (white/red) to connect AUDIO OUT (L/R) jacks of the DVD Player to the corresponding AUDIO IN jacks on the stereo system (cable not supplied).

*Tip:*
*- Analogue audio out will not have sound if DTS playback is selected.*

## Connecting to a Digital AV Receiver




### Receiver has a PCM, Dolby Digital or MPEG decoder

1. Select one of the video connections (CVBS VIDEO IN or COMPONENT VIDEO IN) depending on the options available on your TV.
2. Connect the COAXIAL jack of the DVD player to the corresponding Digital Audio In jack on your Receiver (cable not supplied).
3. Set the DVD Player' s Digital Output to PCM-Only or ALL depending on the capabilities of your Receiver (see page 18 { Digital Output }).

*Tip:*
*-If the audio format of the Digital Output does not match the capabilities of your receiver, the receiver will produce a strong, distorted sound or no sound at all.*

## Connecting the power cord




After everything is connected properly, plug in the AC power cord to the power outlet.
Never make or change any connections with the power switched on.

“ no disc “ will appear on the display window when you press the ON/STANDBY button with no disc loaded.

***Helpful hint:*** before making or changing any connections, make sure that all the devices are disconnected from the power outlet.

English

## Front and Rear panels

**Disc tray**
Place a disc here

**Display**
Shows information about the current status of the DVD Player

**IR Sensor**
Points the remote control towards this sensor.

**I/⏻ ON/STANDBY**
Turns the player on or switches it to stand-by mode

**►/II PLAY/ PAUSE**
Starts or pauses playback

**■STOP**
Stops playback

**▲OPEN/CLOSE**
Opens or closes the disc tray




**MAINS ~**
Connects to a standard AC outlet.

**Audio Out (Left/Right)**
Connects to Audio input of a TV, an amplifier, receiver or stereo system

**COAXIAL(Digital audio out)**
Connects to coaxial Audio input of a digital audio equipment

**YPBPR Component Video Out**
Connects to YPBPR input of a TV

**Video Out (CVBS)**
Connects to CVBS Video input of a TV



# Product Overview(continued)

## Remote Control

See the page in [ ] for details.




**[ 14 ] DISPLAY**
-Displays information on TV screen during playback

**[ 12 ] OPEN/CLOSE**
-Open/close the disc tray

**[ 13, 14, 19 ] Number Buttons**
-Selects numbered items in a menu
-Press to enter track/chapter/title numbers or password directly

**[ 13 ] +10 button**
- Press to enter number greater than 9

**[ 13, 14 ] MENU**
-Enters or exits the disc contents
-Switches on or off the Playback Control (PBC) mode (for VCD version 2.0 only)

**[ 14 ] OK**
-Acknowledge menu selection

**[ 15 ] RETURN**
-To go back to previous menu

**[ 14 ] TITLE**
-Show title menu

**[ 13, 15 ] F.R & F.F**
-Do a forward/reverse search

**[ 12, 14, 15 ] PREV & NEXT**
-Skip to previous or next chapter /track

**[ 13 ] REPEAT**
-Selects various repeat mode

**[ 14 ] A-B**
-Repeats playback from point A to B on a disc

**[ 13 ] SLOW**
-Do a slow forward

**[ 13 ] CLEAR**
-Delete the mistyped entries or cancel some functions

**REMOTE SIGNAL EMITTER [ 10 ]**
-Point remote control to the sensor on the front panel

**⏻ ON / STANDBY [ 7, 12 ]**
-To switch the DVD player to ON or standby mode

**T - SEARCH [ 14 ]**
-Start playback from a designated point

**SETUP [ 10, 16 ]**
-Enters or exits the system setup menu

**◀ ▶ ▲ ▼ [ 13, 16 ]**
-Cursor buttons for moving to the left / right / up / down
-To rotate the JPEG picture during playback

**STEP**
-Play video frame by frame

**PLAY/PAUSE ▶|| [ 12 ]**
-Starts or pauses playback

**STOP ■ [ 13 ]**
-Stops play

**SUBTITLE [ 14 ]**
-To access subtitle language

**ANGLE [ 14 ]**
-Switch the camera angle during playback

**AUDIO [ 14 ]**
-Selects an audio setting (DVD) or an audio channel (VCD)

**ZOOM [ 13,16 ]**
-Enlarge a picture on the TV

**RANDOM [ 15 ]**
-Toggles between Normal and Random playback

**PROG [ 13 ]**
-To program playback or cancel the program playback

## Inserting Batteries



1. Open the battery compartment.
2. Insert two batteries type R03 or AAA, following the indications (+ / - ) inside the compartment.
3. Close the cover.

**CAUTION:**
Never throw batteries into a fire.
**Notes:**
- Be sure to use AAA size batteries.
- Dispose of batteries in a designated disposal area.
- Batteries should always be disposed of with the environment in mind. Always dispose of batteries in accordance with applicable laws and regulations.
- If the remote control does not operate correctly, or if the operating range becomes reduced, replace batteries with new ones.
- When necessary to replace batteries in the remote control, always replace both batteries with new ones. Never mix battery types or use new and used batteries in combination.
- Always remove batteries from remote control if they are dead or if the remote control is not to be used for an extended period of time. This will prevent battery acid from leaking into the battery compartment.

## Using the Remote Control to Operate the System




1. Aim the Remote Control directly at the remote sensor (IR) on the front panel.
2. Do not put any objects between the Remote Control and DVD Player while operating the DVD Player.

## Finding your viewing channel

1. Press I/⏻ ON/STANDBY on the DVD player to turn it on.
2. Turn on the TV and set it to the correct video-in channel. You should see the blue DVD background screen.
   ➔Usually these channels are between the lowest and highest channels and may be called FRONT, A/V IN or VIDEO. See your TV' s manual for more details.
   ➔Or, you may go to channel 1 on your TV, then press the Channel down button repeatedly until you see the Video In channel.
   ➔Or, the TV remote control may have a button that chooses different video modes.
   ➔Or, tune the TV until you can see the signal from the RF modulator (refer to your TV user manual).
3. If you are using external equipment, (such as audio system or receiver), turn it on and select the appropriate input source for the DVD player output. Refer to the equipment user's manual for detail.

## Setting up Progressive Scan feature

**(for Progressive Scan TV only)**
The progressive scan display twice the number of frames per seconds than interlaced scanning (ordinary normal TV system). With nearly double the number of lines, progressive scan offers higher picture resolution and quality.

Before you start...
-Ensure that you have connected this DVD player to a progressive scan TV using the Y PB PR connection ( see page 6).
-Ensure that you have completed the basic installation and set up.

1. Turn on your TV and select the video input connected to the DVD video player (refer to your TV user manual).
2. Press ⏻ ON/STANDBY on the remote control to turn on the DVD player.
   ➔The blue DVD background screen will appear on the TV.
3. Press SETUP.
4. Press ▲/▼ to select { **Video** }, then press ▶.

5. Press ▲/▼ to select { **Video Out** }, then press ▶.
6. Press ▲/▼ to select { **P- Scan** }, then press OK to confirm.
   ➔The menu will appear on the TV.

***Helpful hint***: Press ◀ to go back to previous menu item.
Press SETUP to exit the menu item.

# Getting Started (continued)/Playback from Disc


Activating Progressive Scan
1.Ensure your TV supports Progressive Mode
2.If there is a distorted picture on the TV, wait 15 seconds for automatic recover
Yes
No

7. Press ◀ to highlight { **Yes** } and press OK to confirm.
   ➔ The reconfirmation menu will appear on the TV

8. Press ◀ to highlight { **Yes** } and press OK to confirm.
   ➔ The setup is now completed and you can start enjoying the high quality picture.

### To deactivate Progressive Scan manually:

1. Wait for 15 seconds for the auto recovery.

**OR**

1. Press OPEN/CLOSE ▲ on the DVD player to open the disc tray.
2. Press number button " 1 " on the remote control for a few seconds.
   ➔The blue DVD background screen appears.

*Tip:*
*-There are some progressive scan TVs and High-Definition TVs that are not fully compatible with this unit, resulting in the unnatural picture when playing back a DVD VIDEO disc in the progressive scan mode. In such a case, turn off the progressive scan feature on both the DVD player and your TV.*

## Setting the language

You can change the On-Screen Display to your desired language where available.

### On-Screen Display (OSD) Language

The On-screen language for the system menu will remain as you set it, regardless of various disc languages.

1. Press SETUP.
2. Press ▲/▼ to select { **Language** }
3. Press ▶ to highlight { **OSD Language** }, then press ▶.
4. Press ▲/▼ to select a language and press OK.

### Audio, Subtitle and DVD menu language

You can choose your own preferred language or soundtrack from audio, subtitles and DVD menu languages. If the language selected is not available on the disc, the disc's default language will be used instead.

1. Press SETUP.
2. Press ▶ to select { **Language** }, then press ▶.
3. Press ▲/▼ to highlight one of the options below, then press ▶.
   { **Subtitle** }
   Select this to change the subtitle language.
   { **Audio**}
   Select this to change the disc soundtrack language.
   { **DVD Menu** }
   Select this to change the language of the disc menu.
4. Use ▲/▼ to select a language and press OK to confirm.
5. Repeat steps 3 - 4 for other language settings.

**IMPORTANT!**
**-DVD discs and players are designed with regional restrictions. Before playing a disc, make sure the disc is for the same zone as your player.**
**-If ' ⃠ 'appears on the TV screen when a button is pressed, it means the function is not available on the current disc or at the current time.**

## Playable discs

Using this DVD player, you can playback on the following discs. Some of these discs may be incompatible.

**DVD Video** disc(Digital Versatile Disc)

**DVD±R/RW** (DVD Recordable / Rewritable)

**DVD±R DL** (Dual layer) (Audio/Video format or MP3/ JPEG files).

***Helpful hint***: Press ◀ to go back to previous menu item.
Press SETUP to exit the menu item.

# Playback from Disc(continued)/Playback Feature



**CD-R** (CD-Recordable)
Audio/Video format or
MP3/JPEG files.

**CD-RW** (CD-Rewritable)
Audio/Video format or
MP3/JPEG files.

**Audio CD** (Compact Disc
Digital Audio)

**Video CD**
(Formats 1.0, 1.1, 2.0)

**Super Video CD**

**MP3-Disc**

**DivX® Disc**
(DivX® 3.11, 4.x, 5.x and 6.0)

Because of problems and errors that can occur during the creation of DVD and CD Software and/or the manufacture of DVD and CD discs. Toshiba cannot assure that this DVD player will successfully play every disc bearing DVD and CD logos. If you happen to experience any difficulty playing a DVD and/or CD disc on this DVD player, please contact Toshiba Customer Service.

DVD is a trademark of DVD Format/Logo Licensing Corporation.

## Supported Fomats

**MP3 tracks**
-The file extensions has to be '.mp3 '.
-JPEG/ISO format.
-Maximum 15 characters display for file name.
-Maximum 8 characters display for folder name.
-Supported sampling frequencies & corresponding bit-rates;
32kHz, 64-320 kbps
44.1kHz, 48kHz 80-320 kbps

**JPEG/Pictures**
-The file extensions has to be '.JPG ' and not '.JPEG' .
-JPEG/ISO format.
-It can only display DCF-standard still pictures or JPEG pictures such as TIFF.

**DivX® movies**
-The file extensions has to be '.AVI', '.MPG' or '.MPEG'.
-DivX® 3.11, 4.x, 5.x and 6.0.
-Q-pel accurate motion compensation.
-Global Motion Compensation (GMC) playback.

*Tips:*
*– Maximum 100 sessions for CD and 10 multi border for DVD are supported.*
*– For DVD-R, DVD-RW multi border, only finalized disc can be supported.*
*– For DVD+R and DVD+RW multi border both finalized and unfinalized disc cannot be supported.*

## Starting disc playback

1. Turn on the TV and select the video input connected to the DVD video player.
2. Press ⏻ ON / STANDBY to turn on the DVD player.
3. Press OPEN/CLOSE ⏏ to open the disc tray.
4. Place a disc onto the disc tray with the label facing up, then press OPEN/CLOSE ⏏.
   ➔For double-sided discs, load the side which you want to play facing up.
5. Playback may start automatically. If not, press PLAY/PAUSE ▶II.
   ➔ If a disc menu appears on the TV, see "Using the disc menu" on page 13.
   ➔If the parental control was activated for the inserted disc, you have to enter your four-digit password , see page 19.
   ➔ For more playback features, see pages 12 - 16.

*Tips:*
*-Do not overturn the DVD player while disc loading, playing or ejecting.*
*-Do not close the disc tray manually even if the power is switched off.*

## Basic playback control

Unless otherwise stated, all operations described are based on Remote Control use.

### Pausing playback

1. During playback, press PLAY/PAUSE ▶II to pause playback and display a still picture.
   ➔Sound will be muted.
2. To resume normal playback, press PLAY/PAUSE ▶II again.

### Skipping chapter/track

● Press PREV I◀◀ / NEXT ▶▶I to go to the previous or next chapter/track during playback.

➔When PREV I◀◀ is pressed after the first 5 seconds of playback, playback will start from the beginning of the current chapter/track. If you press the button within the first 5 seconds, playback will start from the beginning of the preceding chapter/track.

● Press DISPLAY twice to display the disc information for title/chapter/track.

***Helpful hint***: Some discs cannot be played on this DVD player due to the configuration and characteristic of the disc, or due to the condition of recording and authorising software

# Playback Feature(continued)

● Use Number buttons (0-9) to enter valid chapter / track number directly. For the track/chapter numbers which are greater than " 9 " , use " +10 " button. Each presses increases the number by 10. Then press the second digit of track number.

➔The playback skips to the selected chapter / track.

*Tip:*
*-For VCD2.0/SVCD discs, accessing tracks using number buttons is not possible if the PBC mode is turned on.*

## Stopping playback

1. During playback, press STOP ■.

●The DVD video player memorises the stopped point. Press PLAY/PAUSE ▶|| to resume playback from the location where you stopped playback.

●If you press STOP ■ again, the DVD video player will cancel the resume function.

*Tips:*
*-Screen saver will start automatically if the disc playback is stopped for about 5 minutes.*
*-The player will automatically switch to Power Standby mode if you do not press any buttons for about 25 minutes after the disc has stopped playing.*

## Program playback

During playback, press PROG, then the OSD will appear as below:

**For VCD:**




**For DVD:**




1. Use the ▲/▼ and OK button to select your desired title/chapter/track in the list.
2. When you have finished programming, press ▶ to move the cursor to the "Play", press the OK button or directly press PLAY/PAUSE ▶|| button to start the program playback.
3. Press CLEAR or select "Clear" to delete one by one from last chosen track / title / chapter or select "Clear All" to clear all the programmed tracks/titles/chapters.
4. Press STOP twice to cancel program playback.

# Operations for video playback (DVD/ VCD/SVCD)

## Using the disc menu

Depending on the disc, a menu may appear on the TV screen once you load in the disc.

**To select a playback feature or item**

●Use ◀/▶/▲/▼ keys or number buttons (0-9) on the remote, then press OK to start playback.

**To access or remove the menu.**

●Press MENU on the remote.

## Zooming In

This function allows you to enlarge the picture on the TV screen and to pan through the enlarged picture.

1. During playback, press ZOOM repeatedly to display the picture with different scales.

●Use ◀/▶/▲/▼ to pan through the enlarged picture.

●Playback will continue.

2. Press ZOOM repeatedly to return to the original size.

## Slow Motion

During playback of DVD, VCD, SVCD and DivX® discs, you can do a slow forward at different speed.

1. Press SLOW during playback to select the required speed: 1/2, 1/4, 1/8 ( forward only ).

➔Sound will be muted.

2. To return to normal speed, press PLAY/ PAUSE ▶||.

## Forward/ Reverse Searching

You can fast forward or fast reverse a disc during playback and select a desired search speed.

**For DivX®, DVD,VCD, SVCD,CD**

1. During playback, press ◀◀ / ▶▶ to select the required speed: X2, X4, X8, X16 (backward or forward).

➔Sound will be muted (DVD/VCD/SVCD/DivX®) or intermittent (CD).

2. To return to normal speed, press PLAY / PAUSE ▶||.

# Selecting various repeat functions

## Repeat play mode

The repeat play options vary depending on the disc type.

1. While playing a disc, press REPEAT repeatedly to choose a repeat options.

**For DVD**

-Repeat Chapter (currently playing chapter)
-Repeat Title (currently playing title)
-Off (cancel)

***Helpful hint***: The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

**For Video CD, Audio CD**
-Repeat Single (currently playing track)
-Repeat All (entire disc)
-Off (cancel)

**For MP3, JPEG, DivX®**
-Repeat Single (currently playing file)
-Repeat All (current folder)
-Off (cancel)

*Tip:*
*-For VCD 2.0/SVCD discs, repeat playback is not possible if the PBC mode is switched on.*

### Repeating a section within a chapter/ track

You can repeat the playback of a specific segment within a chapter or track. To do this, you must mark the start and end of the segment you want.

1. While playing a disc, press A - B at your chosen starting point.
2. Press A - B again at your chosen end point.
   ➔ The section will now repeat continuously.
3. To exit the sequence, press A - B.

## Viewing the disc playback information

You can view the disc information (such as current title/chapter/track number, total playing time or remaining time on the disc) without interrupting the disc playback.

1. During playback, press DISPLAY repeatedly on the remote control.
   ➔The available disc information appears on the TV screen with the following sequence.

Time
Time 00:03:33 (DVD)
Title / Chapter
Title 1/1 Chapter 6/16 (DVD)
Audio
Audio 1/1 DD 6Ch Eng (DVD)
Subtitle
Subtitle 1/8 Eng (DVD)
Angle
Angle 1/4 (DVD)
Time
Time 00：03：33 (VCD)
Track
Track 1/15 (VCD PBC OFF)
OR
PBC On (VCD PBC ON)

### Title/Time/Chapter/Track selection

1. Press T-SEARCH, then press ▲/▼ to select { Time} / { Title } / { Chapter } or { Track }, press OK to access.

**For VCD**：
PBC OFF
Track ---
Track Time --:--:-- (desired time of the current track)
Disc Time --:--:-- (desired time of the disc)
PBC ON
Time --:--:-- (desired time of the current track)

**For DVD:**
Title ---
Chapter ---
Time --:--:-- (desired time of the disc)

2. Use the number buttons ( 0-9 ) to input a desired number or time. (This function only apply to DVD/ VCD/CD/SVCD.)
3. Press OK to confirm.
   ➔The playback skips to the chosen title/chapter/ track/time.

### Angle

● When {Angle} information appears on the screen, press ANGLE button on the remote control repeatedly to switch to different angles.
➔Playback will go to the selected angle.

## Special DVD Features

### Playing a Title

1. Press TITLE.
   ➔The disc title menu appears on the TV screen.
2. Use ▲/▼/◀/▶ or number buttons (0-9) to select a play option.
3. Press OK to confirm.

### Changing the Audio Language

**For DVD**：
Press AUDIO repeatedly to select different audio languages.

**Changing the Audio Channel**
**For VCD**：
●Press AUDIO to select the available audio channels provided by the disc (Left, Right, Mix, Stereo)

### Subtitles

●Press SUBTITLE repeatedly to select different subtitle languages.

## Special VCD and SVCD Features

**For VCD with Playback Control ( PBC ) feature (version 2.0 only)**
●Press MENU to toggle between ' PBC On ' and ' PBC Off '.
➔If you select ' PBC On ', the disc menu ( if available ) will appear on the TV.
➔Use the number buttons ( 0-9 ) to select a play option.
●Press PREV ⏮ / NEXT ⏭ to go to the previous or next track.

***Helpful hint***: The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

# Playback Feature(continued)

➔When PREV I◄◄ is pressed after the first 5 seconds of playback, playback will start from the beginning of the current track. If you press the button within the first 5 seconds, playback will start from the beginning of the preceding track.

●During playback, pressing RETURN will return to the menu screen (if PBC is on).

**If you want to skip the index menu and playback directly from the beginning.**

●Press MENU on the remote control to turn the PBC off.

## Playing a DivX® Disc

This DVD player supports the DivX® movie playback that you download from your computer onto a CD-R/RW or DVD±R/RW (see page 12 for more information).

1. Load a DivX® disc.
   The data disc menu appears on the TV screen.
2. Press ▲/▼ to select the folder and press OK to open the folder.
3. Press ▲/▼ to select a file.
4. Press OK to confirm.

● Press SUBTITLE on the remote control will turn on or off the subtitle.

● If multilingual subtitles are embedded on the DivX® disc, pressing SUBTITLE will change the subtitle language during playback.

*Tips:*
*–Subtitle files with the following filename extensions (.srt, .smi, .sub, .ssa, .txt) are supported but do not appear on the file navigation menu.*
*–The subtitle filename(.sub) has to be saved under the same filename as the movie(.avi) in the same folder.*
*[For example, Folder A: abc.avi and abc.sub]*

## Playing MP3/JPEG/ Kodak Picture CD

**IMPORTANT!**
**You have to turn on your TV and set to the correct Video In channel. (See page 10, "Finding your viewing channel.")**

### General Operation

1. Load a disc.

   ➔The disc reading time may exceed 30 seconds due to the complexity of the directory/file configuration.

   ➔The data disc menu and ID3 (MP3) information (includbing at least title, singer and album) appears on the TV screen.

2. Press ▲ / ▼ to select the folder and press OK to open the folder.
3. Press ▲ / ▼ to select a track/file.
4. Press **OK** to confirm.

*Tips:*
*- If you highlight on a jpeg file, a preview will appear.*
*- During MP3 playback, the LED will display the time (M : S).*
*- During JPEG playback, the LED will display moving bars "-----".*

### Playback Selection

During playback, you can;

● Press PLAY/PAUSE ►II repeatedly to pause/resume playback.

● Press PREV I◄◄ / NEXT ►►I to go to the previous or next track/file.

**For MP3**

● Within the first 5 seconds, press PREV I◄◄ to go back to the previous track.

●After the first 5 seconds of playback, press PREV I◄◄ to go back to the beginning of current track.

● During playback, press F.R ◄◄ / F.F ►► to access fast forward or fast reverse with the required speed: X2, X4, X8, X16.

### Play modes for MP3/Audio CD/JPEG/ DivX®

You are able to modify the play modes through the Toolkit which appears on the right of the file menu. Press ◄ / ► to navigate between the windows and ▲ / ▼ buttons to select files/ tracks or play mode items. Then press OK . Please refer to below steps to playback files /tracks in the **Program View** list:

1. Select **Edit Mode** in the Toolkit then press OK to start Edit Mode.
2. Select a file/track or more if you want in the original view list.
3. Select **Add To Program** in the toolkit then press OK. '√' will disappear from screen. It means that the files/tracks you selected have already added into the **Program View** list.
4. Select **Program View** in the Toolkit then press OK to open the files/tracks in the Program View list that you already selected in step 2.
5. Press PLAY/PAUSE ►II to playback all files/tracks in the Program View list.

**The toolkit has the following play mode items:**

● **Filter** ( **Audio/Photo/Video** ): Sets file filters

● **Repeat** (**Off/Single/ All**):

**Off**: Resumes normal playback

**Single**: Repeat the current track/file.

**All**: Repeats files on the current folder or all tracks on the disc.

● **Mode**(**Normal/Random**)

This mode can also be toggled by using RANDOM button.

Normal: Resumes normal playback

Random: Playbacks track/file in random order.

● **Edit Mode**: Program operation works only when Edit Mode is selected. After finish storing the files/ tracks you want into the program view list, select "Edit Mode" again and press OK to release edit

***Helpful hint***: The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

mode.

- **Program View:** To view tracks/files in the Program View list. It is disabled if the Program View list is empty.
- **Add to Program**: Add files/tracks to the Program View list. It is disabled if Edit Mode is not selected.(Only 10 files/tracks can be selected each time to add to program. The maximum number of files/tracks can be added is 30.)
- **Browser View**: To view files/tracks in the Original View list.
- **Clear Program**: Delete the files/tracks in the Program View list.

➔Select a file/track or more you want to delete in stop mode." √ " will appear besides the deleted file/track.
Select Clear Program and then press OK. It is disabled if Edit mode is not selected.

*Tip:*
*-Filter mode is not applicable to Audio CD.*

### Zoom picture (JPEG)

- During playback, press ZOOM repeatedly to display the picture with different scales.
- Use ▲ / ▼ / ◀ / ▶ to view the zoomed picture.

### Rotate picture (JPEG)

- During playback, press ▲ / ▼ / ◀ / ▶ to rotate the picture on the TV screen.

▲ / ▼: flip the picture vertically by 180º
◀: rotate the picture anti-clockwise by 270º
▶: rotate the picture clockwise by 90º

*Tip:*
*-It may not be possible to play certain MP3/JPEG disc due to the configuration and characteristics of the disc or condition of the recording.*

This DVD Player setup is carried out via the TV, enabling you to customise the DVD player to suit your particular requirement.

## Using the Language setup menu

1. Press **SETUP** on the remote control.
   ➔ The system setup menu appears.

2. Press ▲ / ▼ to select {**Language** }, then press ▶.
3. Press ▲ / ▼ to select an item, then press ▶ to access.
   Example: { **OSD Language** }
   ➔The options for the selected item appears.
   ➔If the selection in the menu is greyed out, that means the feature is not available or not possible to change at the current state.
4. Use ▲/▼ to select a setting and press OK to confirm.
   Example: { **English** }
   ➔The setting is selected and setup is completed.
5. To exit, press SETUP.

### OSD Language

This menu contains various language options for the language displayed on the screen.

### Subtitle/Audio/DVD Menu

These menus contains various language options for audio, subtitle and DVD menu which may be recorded on the DVD.

*Tips:*
*-Some DVD video discs may be set to display subtitles in a different language other than you selected. A prior subtitle language may be programmed on the disc.*
*-Some DVD video discs allow you to change subtitle selections only via the disc menu. If this is the case, press the MENU button and choose the appropriate subtitle language from the selection on the disc menu.*
*-Some DVD video discs may not be played in a different audio language that you selected. A prior language may be programmed on the disc.*
*-Some DVD discs may not include your pre-selected language . In this case, the DVD video player automatically displays discs menus consistent with the disc's initial language setting.*

### DivX® Subtitle

If your DivX® files include a subtitle file (see page 15 for the supported file formats), you may select a supported DivX® subtitle language by region.

1. In 'Language', press ▲/▼ to select { **DivX Subtitle** }, then press ▶.

{ **Standard** }
Albanian, Danish, Dutch, English, Finnish, French, Gaelic, German, Italian, Kurdish (Latin), Norwegian, Portuguese, Spanish, Swedish and Turkish.

**{ Central European }**
Albanian, Croat, Czech, Dutch, English, German, Hungarian, Irish, Polish, Romanian, Slovak, Slovene and Sorbian.

**{ Cyrillic }**
Bulgarian, Belorussian, English, Macedonian, Moldavian, Russian, Serbian and Ukrainian.

**{ Greek }**
English and Modern Greek only.

**{ Hebrew }**
English and Modern Hebrew only.

2. Use ▲/▼ to select a setting and press **OK** to confirm.

***Helpful hint***: Press ◀ to go back to previous menu item.
Press SETUP to exit the menu item.

# DVD Menu Options (continued)

English

## Using the Video setup menu

1. Press **SETUP** on the remote control.
   ➔The system setup menu appears.




2. Press ▲ / ▼ to select { **Video** }, then press ▶
3. Press ▲ / ▼ to select an item, then press ▶ to access.
   Example: { **Video Out** }
   ➔The options for the selected item appears.
   ➔If the selection in the menu is greyed out, that means the feature is not available or not possible to change at the current state.
4. Use ▲ / ▼ to select a setting and press OK to confirm.
   Example: { **P-Scan** }
   ➔The setting is selected and setup is completed.
5. To exit, press SETUP.

### Aspect Ratio

The picture shape can be adjusted to fit your TV and the format must be available on the playback disc. Otherwise, the TV display will not affect the picture during playback.

1. In ' Video ', press ▲ / ▼ to select {**Aspect Ratio** }, then press ▶.
   { **4:3** }
   Select this if you have a normal TV. A ' wide-screen ' source, display with black bars on the top and bottom will be displayed on the TV screen.
   { **16:9** }
   Select this for wide-screen TV (frame ratio 16:9).
2. Use ▲ / ▼ to select a setting and press OK to confirm.

### View Mode

Use view mode to scale an image that fits to the TV screen's width and height.

1. In ' Video ', press ▲ / ▼ to select { **View Mode** }, then press ▶.
   { **Fill** }
   Fill the screen with decoded image.
   { **Original** }
   Display image as its original size.
   { **Height Fit** }
   Fit the screen height with image height.
   { **Width Fit** }
   Fit the screen width with image width.
   { **Auto Fit** }
   Automatically fit the decoded image on screen without distortion.
   { **Pan Scan** }
   Automatically display decoded image on full screen without distortion.
2. Use ▲ / ▼ to select a setting and press OK to confirm.
   *Tip:*
   *- Depending on the type of discs, you may not be able to view the mode as selected.*

### TV System

The video standard of the DVD player output can be selected from “NTSC”, “PAL” or “Multi”.
**{ NTSC }**: Select if your TV system is NTSC.
**{ PAL }**: Select if your TV system is PAL.
**{ Multi }**: The DVD video player automatically identifies PAL or NTSC video system of a disc. Connect a multisystem TV (PAL/NTSC compatible) to view a picture.
A playback picture may be distorted when detected a signal change between PAL and NTSC on the disc. For the case of Progressive mode, your multisystem TV must be able to support 525p and 625p.

### Video Out

. The video output of the DVD player can be selected as “Component” or “P-Scan”.

1. In ' Video ', press ▲ / ▼to select { **Video Out** }, then press ▶.
   { **Component** }
   Select this for component video connection.
   { **P-Scan** }
   Select this when you connect your DVD player to your TV, which has component video inputs that supports progressive scan.
2. Use ▲ / ▼ to select a setting and press OK to confirm.

### Smart Picture

This DVD player provides four predefined sets of picture color settings.

1. In ' Video ', press ▲ / ▼ to select {**Smart Picture** }, then press ▶.
   { **Standard** }
   Select this for a preset standard picture setting.
   { **Vivid** }
   Select this to make the picture brighter.
   { **Cool** }
   Select this to make the picture softer.
   { **Personal** }
   Select this to personalise your picture color by adjusting the brightness, contrast, tint and color (saturation).
2. Use ▲ / ▼ to select a setting and press OK to confirm.
3. If you select { **Personal** }, then proceed to steps 4~7.
   ➔The setup menu appears.




***Helpful hint***: Press ◀ to go back to previous menu item.
Press SETUP to exit the menu item.

4. Press ▲ / ▼ to highlight one of the following options.
   **Brightness**
   Increase the value to brighten the picture or vice versa. Choose zero (0) for average setting.
   **Contrast**
   Increase the value to sharpen the picture or vice versa. Choose zero (0) to balance the contrast.
   **Tint**
   Increase the value to darken the picture or vice versa. Choose zero (0) for average setting.
   **Color**
   Increase the value to enhance the color in your picture or vice versa. Choose zero (0) to balance the color.
5. Press ◄ / ► to adjust the setting that best suits your personal preference.
6. Repeat steps 4~ 5 for adjusting other color features.
7. Press OK to confirm.

## Using the Audio setup menu

1. Press SETUP on the remote control.
   ➔The system setup menu appears.




2. Press ▲ / ▼ to select { **Audio** }, then press ►.
3. Press ▲ / ▼to select an item, then press ► to access.
   Example: { **Night Mode** }
   ➔The options for the selected item appears.
   ➔If the selection in the menu is greyed out, that means the feature is not available or not possible to change at the current state.
4. Use ▲ / ▼ to select a setting and press OK to confirm.
   Example: { **On** }
   ➔The setting is selected and setup is completed.
5. To exit, press SETUP.

### Digital Output

Select this if you connect to a multichannel decoder/ receiver.

1. In 'Audio', press ▲ / ▼ to select { **Digital Output** }, then press ►.
   { **All** }
   Select this if the connected device has a built-in multichannel decoder that supports one of the multichannel audio format (Dolby Digital, DTS).
   { **PCM** }
   Select this if the connected device is not capable of decoding multichannel audio. The DVD player will convert the Dolby Digital signal to PCM (Pulse Code Modulation).
   { **Off** }
   To deactivate the digital audio output. For example, if you use the AUDIO OUT jacks to connect to a TV or stereo system.
2. Use ▲ / ▼ to select a setting and press OK to confirm.

*Tips:*
*-If { Digital Output } is set to { All }, all audio settings except MUTE are invalid.*
*-When playing MPEG , MP3 and set Digital Output to {ALL}, the player will output PCM signals.*

### Night Mode

This mode optimises playback of sound at low volume. High volume outputs will be softened and low volume outputs are brought upward to an audible level.

1. In 'Audio', press ▲ / ▼ to select { **Night Mode** }, then press ►.
   { **On** }
   Select this to set low volume output. This feature is only available for movie discs with Dolby Digital mode.
   { **Off** }
   Turns off night mode feature. Select this to enjoy the surround sound with its full dynamic range.
2. Use ▲ / ▼ to select a setting and press OK to confirm.

### Down Sampling

You can enable and disable the digital signal for better sound output quality.

1. In 'Audio', press ▲ / ▼ to select { **Down Sampling** }, then press ►.
   { **Off** }
   If your amplifier / decoder is compatible with 96 kHz PCM, select "Off". Sound is sampled at 96 kHz.
   { **On** }
   If your amplifier / decoder is NOT compatible with 96 kHz PCM, select "On". Sound recorded at 96 kHz is down sampled to 48 kHz.
2. Use ▲ / ▼ to select a setting and press OK to confirm.

*Tip:*
*- When playing back disc with copyright protection, the sound will be down sampled to 48 kHz even when you select Down Sampling off.*

### 3D

To obtain expansive virtual surround sound effects from two speakers, select 3D to On. This enhancement sounds only output from the analogue Audio out (L/R) jacks of the DVD player.

1. In 'Audio', press ▲ / ▼ to select { **3D** }, then press ►.
   You can set to { **Off** } or { **On** }.
2. Use ▲ / ▼ to select a setting and press OK to confirm.

*Tip:*
*- Only effective in playback of a DVD video disc with Dolby Digital 5.1 bitstream.*

***Helpful hint***: Press ◄ to go back to previous menu item.
Press SETUP to exit the menu item.

# DVD Menu Options (continued)

English

## Using the Rating setup menu

1. Press **SETUP** on the remote control.
   ➔The system setup menu appears.




2. Press ▲ / ▼ to select {**Rating** }, then press ▶.
3. Press ▲ / ▼ to select an item, then press ▶ to access.
   Example: { **Parental control** }
   ➔The options for the selected item appears.
   ➔If the selection in the menu is greyed out, that means the feature is not available or not possible to change at the current state.
4. Use ▲ / ▼ to select a setting and press OK to confirm.
   Example: { **8 Adult** }
   ➔The setting is selected and setup is completed.
5. To exit, press **SETUP**.

### Rating Level settings

Depending on the DVD, you may be asked to change the parental level while playing the disc. The rating levels are from 1 to 8 and are country dependent. You can prohibit the playing of certain discs that are not suitable for your children, or have certain discs played with alternative scenes.

1. In ' Rating ', press ▲ / ▼ to select {**Parental control** }, then press ▶.
2. Use the number buttons to enter the four-digit password , then press OK.(See “Changing the Password” on this page.)
3. Press OK again to list the parental level.
   { **1.Kid Safe** }
   Childsafe; acceptable for viewers of all ages.
   { **2. G** }
   General Audience; recommended as acceptable for viewers of all ages.
   { **3. PG** }
   Parental Guidance suggested.
   { **4. PG-13** }
   Unsuitable for children under age 13.
   { **5. PG-R** }
   Parental Guidance; recommended that parents restrict children under 17 from viewing.
   { **6. R** }
   Restricted; recommended only when supervised by a parent or adult guardian.
   { **7. NC-17** }
   No Children under age 17; not recommended viewing for children under age 17.
   **{ 8. Adult }**
   Mature Material; should be viewed only by adults due to graphic sexual material, violence or language.
4. Use ▲ / ▼ to select a rating level and press OK to confirm.
   ➔Select { **8 Adult** } to disable parental level and allow virtually all discs to play.

   ●DVDs that are rated higher than the level you selected will not play unless you enter your four-digit password.

   *Tips:*
   *-This feature will not limit viewing if the disc manufacturer did not code the disc.*
   *-VCD, SVCD, CD have no level indication, so parental control has no effect on these type of discs. This also applies to most illegal DVDs.*
   *-Some DVDs are not coded with a rating though the movie rating may be printed on the disc cover. The rating level feature does not prohibit play of such discs.*

### Changing the Password

You need to enter your four-digit password to play a prohibited disc or if prompted for a password.

1. In 'Rating', press ▲ / ▼ to select {**Set Password** }, then press OK.
   ➔You will be prompted to enter your four-digit password.

2. Use the number buttons (0-9) to enter the four-digit password, then press OK.
   ➔When doing this for the first time, enter the default password " 0000 ".
   ● If you forget your old four-digit password, enter the default password " 0000 ".
3. Press OK again to enter the new four-digit password.
   ➔The new four-digit password will now take effect.

4. Press OK to confirm.

## Using the Misc (Miscellaneous) setup menu

1. Press SETUP on the remote control.
   ➔ The system setup menu appears.




2. Press ▲ / ▼ to select { **Misc** }, then press ▶.
3. Press ▲ / ▼ to select an item, then press OK to access.

***Helpful hint***: Press ◀ to go back to previous menu item.
Press SETUP to exit the menu item.

Example: { **Use Default Settings** }
➔The options for the selected item appears.
➔If the selection in the menu is greyed out, that means the feature is not available or not possible to change at the current state.

4. Use▲ / ▼ to select a setting and press OK to confirm.
Example: { **No** }
➔The setting is selected and setup is completed.
5. To exit, press SETUP.

## Restoring to original settings

Setting the { **Use Default Settings** } function will reset all options and your personal settings to the factory defaults, except your password and rating level.

1. In ' **Misc** ', press ▲ / ▼ to select **{ Use Default Settings },** then press **OK**.
➔The menu will appear.




{ **Yes** }
Select this to reset to factory default settings.
{ **No** }
Select this to close the menu.

2. Use ◀ / ▶ to select a setting and press OK to confirm.

## DivX® Registration

DivX® registration code allows you to rent and purchase movies using the DivX® VOD service from the internet.
For more information, visit website: www.divx.com/vod.

1. In 'Misc', press ▲/▼ to select { **DivX Registration** }, then press OK.
➔The registration code will appear.
2. Use the registration code to rent or purchase the movies from DivX® VOD.
Registration service at www.divx.com/vod.
➔Follow the instructions and download the movie from your computer onto a CD-R/RW for playback on this DVD player.

*Tips:*

– *All the downloaded movies from DivX® Registration can only be played back on this DVD player.*
– *Time search feature is not available during DivX® movie playback.*

## Tray Lock

Press SETUP button, then press the number button "2006" in sequence to lock the tray.
● All functionality of the player and playback remain the same except for the OPEN/CLOSE button.
● After the tray is locked, "Tray Lock Is On" will appear on the screen when OPEN/CLOSE is pressed.
● To unlock the tray, just follow the same procedure as above.

# Specifications

English

## DVD Video player/Outputs/Supplied Accessaries

### DVD Video player

| | |
|---|---|
| Power supply | 110 V -240V AC, 50/60 Hz |
| Power Consumption | 12W |
| Mass | 1.5 kg |
| External dismensions | 430 X 43 X 209 mm (W/H/D) |
| Signal System | PAL, NTSC |
| Laser | Semiconductor laser, wavelength 650/780 nm |
| Frequency range | DVD linear sound : 48 kHz sampling 4 Hz to 22 kHz<br>96 kHz sampling 4 Hz to 44 kHz |
| Signal-to-noise ratio | More than 90 dB |
| Audio dynamic range | More than 80 dB |
| Harmonic distortion | Less than 65 dB |
| Wow and flutter | Below measurable level [(less than ± 0.001 % ( W.PEAK )] |
| Operating conditions | Temperature : 5°C to 35°C Operation status :Horizontal |

### Outputs

| | |
|---|---|
| Video output (phone type) | 1.0 V ( p-p ) , 75 Ω negative sync., pin jack x 1 |
| Component video output | (Y) 1.0 (p-p), 75 Ω negative sync., pin jack x 1<br>($P_B$)/($P_R$) 700 mV (p-p), 75 Ω, pin jack x 2 |
| Audio output ( COAXIAL DIGITAL ) | 0.5 V (p-p) 75 Ω pin jack x 1 |
| Audio output (ANALOG) | 2.0 V (rms), 680 Ω, pin jacks (L/R) x 1 |

### Supplied Accessories

| | |
|---|---|
| Audio/Video cable | |
| Remote control(SE-R0268) | |
| Batteries(AAA) | |

- The model complies with the above specifications.
- Designs and specifications are subject to change without notice.
- This model may not be compatible with features and /or specifications that may be added in the future.

# Troubleshooting



**WARNING**

**Under no circumstances should you try to repair the DVD player yourself, as this will invalidate the warranty. Do not open the DVD player as there is a risk of electric shock.**

**If a fault occurs, first check the points listed below before taking the DVD player for repair. If you are unable to remedy a problem by following these guides, consult your dealer or TOSHIBA for help.**

| Problem | Solution |
|---|---|
| **No power** | -Check if the AC power cord is properly connected.<br>-Press the I/⏻ ON/STANDBY on the front of the DVD player to turn on the power. |
| **No picture** | -Refer to your TV' s manual for correct Video In channel selection. Change the TV channel until the DVD screen is displayed.<br>-Check if the TV is switched on.<br>-If the progressive scan feature is activated but the connected TV does not support progressive signals or the cables are not connected accordingly. See pages 10-11 for proper progressive scan set up or to deactivate the progressive scan feature. |
| **Distorted picture** | -Sometimes a small amount of picture distortion may appear depending on the disc being played back. This is not malfunction. |
| **Picture clipped** | -May be caused by View Mode Setting (see page 17). Set to original for normal viewing. |
| **Completely distorted picture or black /white picture with DVD.** | -Connect DVD Player directly to the TV.<br>-Make sure the disc is compatible with the DVD player.<br>-Ensure that the DVD Player's setting is set to match that of the disc and your TV. |
| **No sound/distorted sound** | -Ajust the volume.<br>-Check that the speakers are connected correctly. |
| **No audio at digital output** | -Check the digital connections.<br>-Check if your reciever can decode MPEG-2 or DTS and if not, please make sure the digital output is set to PCM.<br>-Check if the audio format of the selected audio language matches your receiver capabilities. |
| **No sound and picture** | -Check that the cable is connected to the correct device (See Connecting to television). |
| **Disc cannot be played** | -The DVD±R/RW must be finalised.<br>-Ensure the disc label is facing up.<br>-Check if the disc is defective by trying another disc.<br>-Wrong region code. |
| **Picture freezes momentarily during playback** | -Check the disc for fingerprint/scratches and clean with a soft cloth wiping from centre to edge. |
| **No return to start-up screen when disc is removed** | -Reset the unit by switching the player off, then on again. |
| **The player does not respond to the Remote Control** | -Aim the Remote Control directly at the sensor on the front of the player.<br>-Reduce the distance to the player.<br>-Replace the batteries in Remote Control.<br>-Re-insert the batteries with their polarities(+/- signs)as indicated |
| **Buttons do not work** | -To completely reset the player, unplug the AC cord from AC outlet for 5-10 seconds. |
| **Player does not respond to some operating commands during playback.** | -Operations may not be permitted by the disc.<br>Refer to the instructions of the disc jacket. |
| **Menu items cannot be selected** | -Press STOP twice before selecting Setup Menu.<br>-Depending on the disc availability,some menu items cannot be selected. |
| **Unable to play DivX® movies.** | -Check that the DivX® file is encoded in 'Home Theatre' mode with DivX® 5.x encoder.<br>-Check that the DivX® movie downloaded is a complete file. |
| **No sound during DivX® movies playback.** | -The audio codec may not be supported by this DVD player. |
| **An DivX® movies does not repeat.** | -Check that file size of the movie does not exceed the file size of the disc during downloading. |
| **Certain DivX® files does not play or are skipped.** | -Make sure the filename extension is correct. (See page 12.)<br>- Recording on another brand of disc or at lower speed.<br>- Ensure that the source file is not corrupted. |